


2 mL Stainless Steel Loading Guidelines

Bead Ruptor Elite

Maximum of 8 tubes can be loaded.

Tubes must be balanced in the tube carriage.




**Place tubes spaced evenly
in the tube carriage.**

Bead Ruptor 96

Minimum of 4 tubes must be loaded.

Tubes must be balanced in the Tube Holder.



**Place tubes spaced evenly
in the Tube Holder.**

